

| Functions | | | OSP-P300A (Smart IF) | OSP-P300 OSP-P200A OSP-P200 (Smart IF) | OSP-E100 OSP-U100 OSP7000 (DNC-T3) | FANUC FOCAS1 FOCAS2 compatible machines | Other company machine MTConnect compatible machines | Other company machines prior to OSP-5020 |
|---------------------------------|----------------------------------|--|-------------------------|---|---|---|--|---|
| Factory operation control | Entire factory display | Operation status (factory layout) | ● | ● | ● | ● | ● | ● |
| | | Maintenance icon display (factory layout) | ● | △ ^{※1} | × | × | × | × |
| | | Operation status table | ● | ● | ● | ● | ● | △ ^{※2} |
| | | Operation history table | ● | ● | ● | ● | ● | ● |
| | | Utilization table | ● | ● | ● | ● | ● | ● |
| | | Breakdown of reasons for non-operation | ● | ● | ● | × | × | × |
| | Individual machine display | Operation time | ● | ● | ● | ● | ● | ● |
| | | Alarm history | ● | ● | ● | × | × | × |
| | | History of operations | ● | ● | ● | × | × | × |
| | | Machining results | ● | ● | ● | × | × | × |
| Machining records management | | | ● | △ ^{※1} | × | × | × | × |
| Remote diagnostics | | | ● | ● | × | × | × | × |

*1. Compatible with OSP suite only *2. Only operation signals from I/O can be acquired